


N86S PNEUMATIC STICK NAILER



PARTS COMMON TO N86S-1 & N86S-2

ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION
1	105591	Cylinder Cap Assembly	26	MRG084431	O-Ring	51	N80321	Mounting Bracket
2	MSC8100-25	Screw, M 8 x 25	27	N80139	Frame	52	MSB6100-12	Hex.Soc.But. Hd. Screw M6x12
†4	MSS5080-5p	Screw, M 5 x 5	28	851880S	Stanley-Bostitch Label	53	MSC6100-30	Hex.Soc. Hd. Cap Screw M6x30
5	N70118	Cylinder Cap Seal	29	851392	Warning Label	54	N80365A	Magazine Assembly
6	N86132	Piston Stop	30	MPP030020	Roll Pin, 3 x 20	55	N80322A	Pusher Assembly
7	854017	Compression Spring	31	102549	Pin, Special Spirol	56	N16175A	Pusher Spring Assembly
8	MRG051531	O-Ring 3.1 x 51.5	32	N70143	Rubber Bushing	57	N80340	Magazine Spacer
10	105578	Head Valve Piston	*33	88459	O-Ring	58	N80323	Spring Spacer
11	851538	O-Ring	*34	MRG019824	O-Ring 1AP20	59	LW8	Lock Washer
††12	N86300	Driver	35	MPW 6.2	Washer 13g	86	N70145	Arm Guide
13	N86107	Main Piston	37	MRG049431	O-Ring 1AG50	††88	N80333	Pusher Bearing Kit
14	851606	O-Ring	38	N70167	End Cap	89	N80325	Latch
15	N86125	Cylinder Seal	39	N86113	Frame Extension	90	N80335	Latch Spring
16	N86108	Cylinder Sleeve	40	N86110	Bumper	91	N80332	Latch Stop
17	89673	O-Ring	41	105022	Locator Plate	92	N80336	Latch Spring bushing
18	N86108	Check Seal	43	MSC8125-28	Screw M 8 x 28	93	MSC4070-45	Hex.Soc.Hd.Cap Screw M4x45
19	N86102	Lower Sleeve	44	N80132	Spring	†††94	N16177	Nail Guide
20	N80354	Nose Gasket	45	N80349	Upper C.T. (Black)	97	MRG002514	O-Ring 1B 1.4 x 2.5
21	N80356	Shock Ring	46	N80348	Nose	98	N100134A	Exhaust Cover
22	N80357	Spacer	47	MSC8125-16	Hex.Soc.Hd.Cap Screw M8x16	99	N100136	Muffler, Exhaust
23	N86105	Cylinder Ring	48	N70120	Torque Nut	100	N100138	Spacer, Muffler
†24	N80363A	Lower C.T. Combination	49	MSB4070-10	Hex.Soc.But. Hd. Screw M4x10	102	N100137	Ring, Bumper
25	MHE6100-100	Elastic Stop Nut M 6	50	MHE4070-100	Elastic Stop Nut M4 x 0.70			

PARTS SPECIAL TO N86S-1

ITEM NO.	PART NO.	DESCRIPTION
***81	TVA# 6	Trigger Valve Assembly
73	N50082A	Trigger Assembly C.T.

PARTS SPECIAL TO N86S-2

ITEM NO.	PART NO.	DESCRIPTION
74	100387	Spring, Trigger
**75	SEQ1	Sequential Trip Parts

†Item #4 is included with Item #1.

††Item #88 includes (4) bearings, (2) screws & (2) nuts.

†††Item #94 included in N80365A magazine assembly (Item #54).

†Item #24 may be ordered with smooth face as N80364A.

††N86301A driver/piston assembly includes Items 12 & 13.

* Items 33 & 34 are included with Item 61.

**SEQ1 is a Conversion Kit (Contact Trip to Sequential Trip)

which includes Valve Assembly, Item 74 Spring, and a Trigger Assembly.

***TVA1 Valve Assembly includes Items 33 & 34

NOTE: For identification: The Sequential Trip Trigger Assembly and the Valve Assembly can be identified by green components.